The Focus Indicator-

Focus status is shown by the focus indicator.

| Focus indicator | Focus status |
|--------------------|--|
| () | Camera focusing. |
| • (lights green) | Subject in focus; focus locked (focus |
| | mode S). |
| (●) (lights green) | Subject in focus (focus mode C). |
| | Focus is automatically adjusted for |
| | changes in distance to subject. |
| (blinks white) | Camera unable to focus. |
| ME | Manual focus (focus mode M). |

