LCD BRIGHTNESS

Adjust monitor brightness.

					Options					
−5	−4	−3	−2	−1	0	+1	+2	+3	+4	+5

LCD COLOR

Adjust monitor saturation.

					Options					
−5	−4	−3	−2	−1	0	+1	+2	+3	+4	+5

LCD COLOR ADJUSTMENT

Adjust the color of the display in the LCD monitor.

1 Adjust colors using the focus stick (focus lever).

2 Press **MENU/OK**.