3 Choose a position for the item and press **MENU/OK**. The item will be added to "my menu".

SELECT ITEM LOCATION
1 IMAGE SIZE
2 IMAGE QUALITY

MOVE   OK SAVE

4 Press **MENU/OK** to return to the edit display.

5 Repeat Steps 3 and 4 until all the desired items have been added.

"My menu" can contain up to 16 items.