۶	BUTTON/DIAL SETTING	
1⁄2	FOCUS LEVER SETTING	224
	EDIT/SAVE QUICK MENU	225
	EDIT/SAVE QUICK MENU	225
	FUNCTION (Fn) SETTING	225
	COMMAND DIAL SETTING	226
	SHUTTER AF	227
	SHUTTER AE	227
	SHOOT WITHOUT LENS	227
2 ⁄2	SHOOT WITHOUT CARD	228
	FOCUS RING	228
	FOCUS RING OPERATION	228
	AE/AF-LOCK MODE	229
	AWB-LOCK MODE	229
	APERTURE RING SETTING (A)	229
	APERTURE SETTING	230
	TOUCH SCREEN SETTING	230
۶	POWER MANAGEMENT	
A	UTO POWER OFF	232
P	ERFORMANCE	233
В	OOST SETTING	233

SAVE DATA SETTING	
FRAME NO.	234
SAVE ORG IMAGE	235
EDIT FILE NAME	235
SELECT FOLDER	236
COPYRIGHT INFO	236
✓ CONNECTION SETTING	
Bluetooth SETTINGS	237
PC AUTO SAVE	238
instax PRINTER CONNECTION SETTING	239
CONNECTION MODE	240
USB POWER SUPPLY SETTING	241
GENERAL SETTINGS	242
INFORMATION	242
RESET WIRELESS SETTING	242