
Taking Photographs (Mode P)

This section describes how to take pictures using program AE (mode P). See pages 56–65 for information on S, A, and M modes.

 Press the DRIVE/DELETE button and select STILL IMAGE in the drive-mode menu.



2 Rotate the shutter-speed dial to **P** and confirm that the camera displays shooting information for program AE.



3 Check the shooting mode.
Confirm that P appears in the display.

