## Fine-Tuning White Balance

Pressing MENU/OK after selecting a white balance option displays a fine-tuning dialog; use the focus stick (focus lever) to fine-tune white balance.



- To exit without fine-tuning white balance, press DISP/BACK after selecting a white balance option.
  - You cannot tilt the focus stick diagonally when fine-tuning white balance.