EF-X8

The following settings are available when an optional EF-X8 shoe-mounted flash unit is attached.



Setting	Description
1 Flash control mode	Choose from the following options: • ITL: TTL mode. Adjust flash compensation (②) and choose a flash mode (③). • M: The flash fires at the selected output (②) regardless of subject brightness or camera settings. Output is expressed in fractions of full power, from ⅓ to ⅙4. The desired results may not be achieved at low values if they exceed the limits of the flash control system; take a test shot and check the results. • M€ (COMMANDER): Choose if the flash is being used to control remote synced flash units, for example as part of a studio flash system. • ⑤OFF (OFF): The EF-X8 does not fire. Flash units connected via the sync terminal will still fire when the shutter is released, but can be disabled by lowering the EF-X8 and turning the units off in the flash settings menu.
2 Flash compensation/	Adjust flash level. The options available vary with the flash
output	control mode ((1)).