## **SHARPNESS**

Options are the same as those for still photography, but settings must be adjusted separately (11).

## **#** HIGH ISO NR

Options are the same as those for still photography, but settings must be adjusted separately (112).

## **INTERFRAME NR**

Select AUTO to automatically adjust interframe noise reduction according to shooting conditions.

Options	
AUTO	OFF



Make the camera is moved "Ghosting" may occur with moving subjects or if the camera is moved during shooting.