

Touch Screen Mode

The LCD monitor also functions as a touch screen.


Shooting Touch Controls

To enable touch controls, select **ON** for **☑** BUTTON/DIAL SETTING > TOUCH SCREEN SETTING > ♣ TOUCH SCREEN SETTING.



EVF

The LCD monitor can be used to select the focus area while pictures are being framed in the electronic viewfinder (EVF). Use BUTTON/DIAL SETTING > TOUCH SCREEN SETTING > EVF/OVF TOUCH SCREEN AREA SETTINGS to choose the area of the monitor employed for touch controls.



If ■ FACE SELECT : is enabled when FACE DETECTION ON is selected for MAF/MF SETTING > FACE/EYE DETECTION SETTING, the face used for focus can be chosen via touch controls.