## Viewing Pictures

Read this section for information on playback zoom and multi-frame playback.

Use the rear command dial to go from full-frame playback to playback zoom or multi-frame playback. Rotate the rear command dial to right or left, the display changes as shown. The display changes in reverse order when rotate the dial to opposite direction.



To cancel playback zoom or multi-frame playback, press  ${\it DISP/BACK}$  or  ${\it MENU/OK}$ .





Full-frame playback



Multi-frame playback







Hundred- frame view