Firmware Updates

Updates to product firmware may result in changes not described in the manual. For more information, visit: *https://fujifilm-x.com/support/download/firmware/*

Checking the Firmware Version

① The camera will only display the firmware version if a memory card is inserted.

1 Turn the camera off and check that a memory card is inserted.

2 Turn the camera on while pressing the **DISP/BACK** button. The current firmware version will be displayed; check the firmware version.

3 Turn the camera off.