Other Controls

Pressing the AEL/AFL button locks both focus and exposure.

- While the assigned control is pressed, pressing the shutter button halfway will not end the lock.
- If AE&AF ON/OFF SWITCH is selected. for BUTTON/DIAL SETTING > AE/ AF-LOCK MODE, the lock can only be ended by pressing the control a second time.



AEL/AFL button (AE/AF lock)



- The focus lever (focus stick) can be used to reposition the focus point during exposure lock.
 - The AEL/AFL button can be assigned other roles using BUTTON/ **DIAL SETTING** > **FUNCTION** (**Fn**) **SETTING**. Exposure and focus lock can also be assigned to other function buttons (\$\equiv 253\$).
 - Exposure and focus lock can be performed separately by assigning them to different function buttons.