

- Install the latest version of the FUJIFILM Camera Remote app on your smartphone or tablet before pairing the device with your camera or uploading images.
 - When ON is selected for both Bluetooth ON/OFF and AUTO IMAGE **TRANSFER** or images are currently selected for upload using the **IMAGE** TRANSFER ORDER option in the (playback) menu, upload to paired devices will begin shortly after you exit to playback or turn the camera off. IMAGE TRANSFER ORDER can also be used to select pictures for upload when AUTO IMAGE TRANSFER is off.

PC AUTO SAVE

Adjust settings for connection to computers via wireless LAN.

Option	Description
PC AUTO SAVE SETTING	Choose the method used for connection to computers via a wireless LAN. • SIMPLE SETUP: Connect using WPS. • MANUAL SETUP: Choose the network from a list (SELECT FROM NETWORK LIST) or enter the name manually (ENTER SSID).
DELETE REGISTERED DESTINATION PC	Remove selected destinations.
DETAILS OF PREVIOUS CONNECTION	View computers to which the camera has recently connected.



These settings also apply when pictures are downloaded to a computer using "FUJIFILM PC AutoSave" software.