AUTOROTATE PB

Choose **ON** to automatically rotate "tall" (portrait-orientation) pictures during playback.

Options	
ON	OFF

FOCUS SCALE UNITS

Choose the units used for the focus distance indicator.

Options	
METERS	FEET

APERTURE UNIT FOR CINEMA LENS

Choose whether the camera displays aperture as a T-number (used for movie camera lenses) or an f/-number (used for still camera lenses) when an optional FUJINON MKX-series lens is attached. For information on using cinema lenses, see the documentation provided with the lens.

Option	Description
-	A measure of lens aperture commonly used by cinematogra-
T NUMBER	phers. Lens transmittance is taken into account to better cal-
	culate exposure.
F NUMBER	A measure of lens aperture commonly used by photographers.
	Lens transmittance is assumed to be 100%, meaning that the
	same aperture may produce different exposures depending on
	the lens.

DISP. CUSTOM SETTING

Choose the items shown in the standard indicator display (11).