Item	Default	
	OVF	**EVF/LCD**
PHOTOMETRY	☑	☑
SHUTTER TYPE	☑	☑
FLASH	☑	☑
CONTINUOUS MODE	☑	☑
TOUCH SCREEN MODE	☑	☑
WHITE BALANCE	☑	☑
FILM SIMULATION	☑	☑
DYNAMIC RANGE	☑	☑
BOOST MODE	☑	☑
FRAMES REMAINING	☑	☑
IMAGE SIZE/QUALITY	☑	☑
MOVIE MODE & REC. TIME	—	☑
DIGITAL TELE-CONV.	☑	☑
CONVERSION LENS	☑	☑
IMAGE TRANSFER ORDER	☑	☑
MIC LEVEL	—	☑
GUIDANCE MESSAGE	☑	☑
BATTERY LEVEL	☑	☑
FRAMING OUTLINE	—	☐

The Setup Menus

8