5 Press MENU/OK. The combined exposures will be displayed as a guide to composing the next shot.



- If you would like to retake the second shot, press the selector left.
 - To end shooting and create a multiple exposure from the shots taken to this point, press DISP/BACK.
- 6 Make additional exposures. Each photograph can contain up to nine exposures.
- **7** Press **DISP/BACK** to end shooting. The camera will create the combined image and multiple exposure shooting will end.