The Network/USB Settings Menu

Adjust camera network and USB settings.