## The DISP/BACK Button

The DISP/BACK button controls the display of indicators in the viewfinder and LCD monitor.



Indicators for the EVF, OVF, and LCD must be selected separately. To choose the indicators displayed in the EVF and OVF, place your eye to the viewfinder and press the DISP/BACK button.



## Viewfinder (OVF)









Full screen

## Viewfinder (EVF)

Standard indicators





