## USB POWER SUPPLY/COMM SETTING

Choose whether USB connections to computers, smartphones, or other devices are used for power delivery or data transfer.

| Option           | Description   |
|------------------|---|
| ΔΠΤΟ             | The camera switches between power delivery and data trans-  |
|                  | fer automatically.  |
| POWER SUPPLY ON/ | The camera draws power from the connected device, reducing  |
| COMM OFF         | the drain on the battery. Data transfer is disabled.        |
| POWER SUPPLY     | The camera can exchange data with, but not draw power from, |
| OFF/COMM ON      | the connected device.                                       |

- The camera cannot draw power from Lightning connections or from devices that do not supply power. Select POWER SUPPLY OFF/COMM ON before connecting the camera to such devices. The connection may not be available for data transfer or the like when POWER SUPPLY ON/COMM OFF is selected.
- Regardless of the option selected, the battery will charge while the camera is off

## INFORMATION

View the camera's MAC, Bluetooth, and wireless network IP addresses.

## **RESET WIRELESS SETTING**

Restore wireless settings to their default values.