
FRAMING GUIDELINE

Choose a framing grid for shooting mode.



Framing guides are not shown at default settings but can be displayed using **Z** SCREEN SET-UP > DISP. CUSTOM SETTING (■ 214).