SELECT FOLDER

Create folders and choose the folder used to store subsequent pictures.

Option	Description
SELECT FOLDER	To choose the folder in which subsequent pictures will be stored, press the selector up or down to highlight an existing folder and press MENU/OK .
CREATE FOLDER	Enter a five-character folder name. The new folder will be created with the next picture you take and subsequent pictures will be stored in that folder.

COPYRIGHT INFO

Copyright information, in the form of Exif tags, can be added to new images as they are taken. Changes to copyright information are reflected only in images taken after the changes are made.

Option	Description	
DISP COPYRIGHT INFO	View the current copyright information.	
	Enter the creator's name.	
ENTER COPYRIGHT INFO	Enter the name of the copyright holder.	
	Delete the current copyright information. This change applies	
	only to images taken after this option is selected; copyright	
	information recorded with existing images is not affected.	

GEOTAGGING

If **ON** is selected, location data downloaded from a smartphone will be embedded in pictures as they are taken.

Options		
ON	OFF	