FLASH SETTING

Adjust flash-related settings.

To display flash-related settings, press MENU/OK in the shooting display and select the (FLASH SETTING) tab.



The options available vary with the shooting mode selected.



FLASH FUNCTION SETTING

Choose a flash control mode, flash mode, or sync mode or adjust the flash level. The options available vary with the flash.



For more information on flash settings, see "External Flash Units" (260) in "Peripherals and Optional Accessories".



RED EYE REMOVAL

Remove red-eye effects caused by the flash.

Option	Description
	A red-eye reduction pre-flash is combined with digital red-eye
	removal.
FLASH	Flash red-eye reduction only.
REMOVAL	Digital red-eye removal only.
OFF	Flash red-eye reduction and digital red-eye removal off.



- Flash red-eye reduction can be used in TTL flash control mode.
 - Digital red-eye removal is performed only when a face is detected.
 - Digital red-eye removal is not available with RAW images.