ZEBRA SETTING

Highlights that may be overexposed are shown by zebra stripes in the movie mode display.

Option	Description						
ZEBRA RIGHT	/// Right-slanting stripes.						
ZEBRA LEFT	Left-slanting stripes.						
OFF	Stripes off.						

ZEBRA LEVEL

Choose the brightness threshold for the zebra stripe display.

Options											
50	55	60	65	70	75	80	85	90	95	100	