## SELECT FOLDER

Create folders and choose the folder used to store subsequent pictures.

Option	Description
	To choose the folder in which subsequent pictures will be
SELECT FOLDER	stored, press the focus stick (focus lever) up or down to
	highlight an existing folder and press MENU/OK.
	Enter a five-character folder name. The new folder will be
CREATE FOLDER	created with the next picture you take and subsequent
	pictures will be stored in that folder.

## **COPYRIGHT INFO**

Copyright information, in the form of Exif tags, can be added to new images as they are taken. Changes to copyright information are reflected only in images taken after the changes are made.

Option	Description
DISP COPYRIGHT INFO	View the current copyright information.
<b>ENTER AUTHOR'S INFO</b>	Enter the creator's name.
<b>ENTER COPYRIGHT INFO</b>	Enter the name of the copyright holder.
	Delete the current copyright information. This change applies
	only to images taken after this option is selected; copyright
	information recorded with existing images is not affected.