
## The Control Ring

Use the control ring for quick access to camera functions during shooting. The function assigned to the control ring can be selected by pressing the control

ring options button. Choose from:



- STANDARD
- WHITE BALANCE
- FILM SIMULATION
- DIGITAL TELE-CONV.



## STANDARD

When STANDARD is selected, the function assigned to the control ring changes with the shooting mode.

Shooting mode	Function
P, S, A, M	Digital teleconverter
Advanced Filter	Filter selection
Panorama/ Multiple Exposure	Film simulation



Regardless of the option selected, when **M** (manual) is chosen with the focus mode selector in shooting mode P, S, A, or M, the control ring can be used only for manual focus.