The DISP/BACK Button

The DISP/BACK button controls the display of indicators in the viewfinder and LCD monitor.



Noticators for the EVF and LCD must be selected separately. To choose the EVF display, place your eye to the viewfinder while using the DISP/BACK button.



Viewfinder

Standard indicators





