9 When prompted, press MENU/OK and adjust settings for connection to the FTP server ( 285).



**10** Save the connection setting profile when adjustments to settings are complete.

Press MENU/OK.

11 Select CREATE NEW.



SELECT CONNECTION SETTING 1/2

1: MUNIVERSAL SETTING

2: MUNIVERSAL SETTING

3: MERCAL SETTING

4: MERCAL SETTING

5: MUNIVERSAL SETTING

6: MUNIVERSAL SETTING

7: MUNIVERSAL SETTING

8: CREATE NEW

12 Name the connection setting profile.

