PERIPHERAL LIGHT CORRECTION

Select ON to enable peripheral illumination correction during movie recording.

Options ON **OFF**

- If **ON** is selected when a lens that does not transmit data to the camera is attached, peripheral illumination will be adjusted according to the option selected for **I**IMAGE QUALITY SETTING > → MOUNT ADAPTER SETTING > PERIPHERAL ILLUMINATION CORRECTION in the shooting menu (# 142).
 - Select **OFF** if you notice banding in movies recorded using this option

This item is also found in the photo menus (1991). Changes to one apply to the other.