FILTER

Take photos with filter effects.

1 Rotate the mode dial to FILTER.



2 Choose a filter via SHOOTING SETTING > FILTER SETTING.

Filter	Description
₩ TOY CAMERA	Choose for a retro toy camera effect.
MINIATURE	The tops and bottoms of pictures are blurred for a diorama effect.
🙉 POP COLOR	Create high-contrast images with saturated colors.
A HIGH-KEY	Create bright, low-contrast images.
ENTER LOW-KEY	Create uniformly dark tones with few areas of emphasized highlights.
See DYNAMIC TONE	Dynamic tone expression is used for a fantasy effect.
 SOFT FOCUS	Create a look that is evenly soft throughout the whole image.
A PARTIAL COLOR (RED)	Areas of the image that are the selected color are recorded in that color. All other areas of the image are recorded in black-and-white.
A PARTIAL COLOR (ORANGE)	
A PARTIAL COLOR (YELLOW)	
A PARTIAL COLOR (GREEN)	
A PARTIAL COLOR (BLUE)	
A PARTIAL COLOR (PURPLE)	

① Depending on the subject and camera settings, images may in some cases be grainy or vary in brightness or hue.