RELEASE/FOCUS PRIORITY

Choose how the camera focuses when the shutter button is pressed all the way down with SINGLE AF or CONTINUOUS AF selected for **FOCUS MODE**

Option	Description
RELEASE	Shutter response is prioritized over focus. Pictures can be taken
	when the camera is not in focus.
FOCUS	Focus is prioritized over shutter response. Pictures can be only
	taken when the camera is in focus.

🗗 📽 AF RANGE LIMITER

Limit the range of available focus distances for increased focus speed.

Option	Description
OFF	Focus limiter disabled.
	Limit focus to a range of distances defined by a minimum and maximum.
CUSTOM	 OK: Limit focus to the selected range. SET: Choose two objects and limit focus to the distance between them.
PRESET1	Limit focus to a preset range.
PRESET2	

- Choosing a focus range that includes distances shorter than the minimum focus distance of the lens disables the focus limiter.
 - The values listed and displayed for the focus limiter may differ from the actual focus distance.
- The following additional operations can be performed when CUSTOM is selected:
 - You can tap objects in the touch screen display to choose the focus range.
 - Instead of tapping an object in the display, you set the maximum focus distance to infinity by rotating the focus ring.
 - Any changes made using this item also apply in movie mode (**1**171).