- Keep the camera steady.
  - The desired results may not be achieved in the subject moves or the composition or lighting changes during shooting.
  - The picture will be cropped a very small amount and the resolution will drop slightly.
  - Mottling may appear in pictures taken at higher values. Choose a value according to the scene.
  - "Extended" sensitivity values are not supported.
  - Depending on the options selected for HDR and sensitivity, pictures may not be taken at the selected shutter speed.
  - The flash does not fire.



Name of the HDR images are indicated by a Image are indicated by a Images are indicated by a Image are indicate