

Shortcut Options

Customize camera controls to suit your style or situation.

Frequently-used options can be added to the **Q** menu or a custom "my" menu or assigned to an **Fn** (function) button for direct access:

Shortcut Option	Description	
"My menu"	Add frequently-used options to this custom menu,	2.45
	which can be viewed by pressing MENU/OK and selecting the M ("MY MENU") tab.	245
	The Q menu is displayed by pressing the Q button.	
	Use the Q menu to view or change the options selected for frequently-used menu items.	247
The function buttons	Use the function buttons for direct access to selected features.	250