FACE/EYE DETECTION SETTING

Enable or disable Intelligent Face Detection when recording movies.

Option	Description
FACE DETECTION ON	See "FACE/EYE DETECTION SETTING" (■ 132).
OFF	Intelligent Face Detection and eye priority off.

If SINGLE AF is chosen for FOCUS MODE when FACE DETECTION ON is selected for MR AF/MF SETTING > FACE/EYE DETECTION SETTING. the camera will automatically switch to **CONTINUOUS AF**. Selecting MANUAL FOCUS when FACE DETECTION ON is selected for FACE/ EYE DETECTION SETTING disables Intelligent Face Detection.

MF ASSIST

Choose how focus is displayed when MANUAL FOCUS is selected for FOCUS MODE.

Option	Description
STANDARD	Focus is displayed normally (focus peaking is not available).
FOCUS PEAK HIGHLIGHT	The camera heightens high-contrast outlines. Choose a color and peaking level.