

SHOOTING SETTING (Still Photography)

Adjust shooting options for still photography.

To display shooting settings, press MENU/OK in the photo shooting display and select the (SHOOTING SETTING) tab.



The options available vary with the shooting mode selected.



AUTO MODE SETTING

Choose the scene selected when the mode dial is rotated to AUTO (68).

FILTER SETTING

Choose the filter used when the mode dial is rotated to FILTER (2 81).