Touch Screen Mode	25
Shooting Touch Controls	25
Playback Touch Controls	30
,	
2 First Steps	31
Attaching the Strap	32
Attaching a Lens	
Inserting the Battery and a Memory Card	34
Compatible Memory Cards	
Charging the Battery	
Turning the Camera On and Off	
Checking the Battery Level	42
Basic Setup	43
Choosing a Different Language	45
Changing the Time and Date	45
Basic Photography and Playback	47
Taking Photographs	48
Viewing Pictures	50
HDMI Output	51
Deleting Pictures	53
4 Movie Recording and Playback	55
Recording Movies	56
Recording Movies	56
Adjusting Movie Settings	62
Viewing Movies	63
Viewing Movies During Playback	63
Viewing Movies During Vlog Recording	64