

## **Function Controls**

Assign a role to each function button or touch-function gesture for quick access to the selected feature.


## The Function Buttons

Assign a role to the function buttons for quick access to the selected feature.

## Function Button Defaults

The default assignments are:

## **Back-of-Camera Function Buttons**



Function buttons	Default
① AFON button	AF-ON
② Center of rear command dial	FOCUS CHECK
③ Q (quick menu) button	QUICK MENU
④ AEL (exposure lock) button	AE LOCK ONLY