

P, S, A, and M Modes


P, S, A, and M modes give you varying degrees of control over shutter speed and aperture.

Mode P: Program AE

Let the camera choose shutter speed and aperture for optimal exposure. Other values that produce the same exposure can be selected with program shift.



Setting	
1 Shutter speed	A (auto)
2 Aperture	A (auto)
	,



Confirm that P appears in the display.

If the subject is outside the metering range of the camera, the aperture display will show "- - -".