☆ ☆ WIRELESS COMMUNICATION

Connect to smartphones running the latest apps. The smartphone can then be used to:

- Control the camera and take pictures remotely
- Receive pictures uploaded from the camera
- Browse the pictures on the camera and download selected pictures
- Upload location data to the camera



- For downloads and other information, visit: https://app.fujifilm-dsc.com/
 - If **? WIRELESS COMMUNICATION** is selected for **☑ BUTTON**/ **DIAL SETTING** > Fn1 BUTTON SETTING, you can connect to the smartphone using the Fn1 button.

DESQUEEZE DISP. IN PLAYBACK

If **ON** is selected, movies taken when **™ MOVIE SETTING** > **IMAGE** FORMAT is set to ANAMORPHIC(35mm) are played back at the magnification specified when taken.

Options	
ON	OFF