Setting	Description
(5) Zoom	The angle of illumination (flash coverage) for units that sup-
	port flash zoom. Some units allow the adjustment to be
	made from the camera. Select AUTO to automatically match
	coverage to focal length when using optional conversion
	lenses.
6 Lighting	If the unit supports this feature, choose from:
	• = (FLASH POWER PRIORITY): Gain range by slightly reducing
	coverage.
	• 🔪 (STANDARD): Match coverage to picture angle.
	• > (EVEN COVERAGE PRIORITY): Slightly increase coverage for
	more even lighting.
(7) LED light	Choose how the built-in LED light functions during still photog-
	raphy (compatible units only): as a catchlight (((CATCHLIGHT),
	as an AF-assist illuminator (AF/AF ASSIST), or as both a catch-
	light and an AF-assist illuminator (%/AF ASSIST+CATCHLIGHT).
	Choose OFF to disable the LED during photography.
7 Number of flashes *	Choose the number of times the flash fires each time the
	shutter is released in MULTI mode.
8 Frequency*	Choose the frequency at which the flash fires in MULTI mode.

^{*} Full value may not be applied if limits of flash control system are exceeded.