## **ISO BKT**

Select a bracketing amount  $(\pm \frac{1}{2}, \pm \frac{2}{3}, \text{ or } \pm 1)$  in the drive mode display. Each time the shutter is released, the camera will take a picture at the current sensitivity and process it to create two additional copies, one with sensitivity raised and the other with sensitivity lowered by the selected amount.

## **WBI WHITE BALANCE BKT**

Select a bracketing amount  $(\pm 1, \pm 2, \text{ or } \pm 3)$  in the drive mode display. Each time the shutter is released, the camera takes one shot and processes it to create three copies: one at the current white balanced setting, one with fine-tuning increased by the selected amount, and another with fine-tuning decreased by the selected amount.