
Conversion Lenses

1 Remove the front ring.



If you have trouble removing the front ring, grip the entire ring and rotate it as shown.



2 Attach the conversion lens.

(1) Keep the front ring and lens cap in a safe place when not in use.