
-Using a Remote Release

A remote release can be used for long time-exposures. When using an optional RR-100 remote release or an electronic release from third-party suppliers, connect it to the camera's microphone/remote release connector via a third-party ø2.5 mm to 3.5 mm adapter.



A confirmation dialog will be displayed if a remote release is connected while the mode dial is rotated to # (movie) or **Vlog**: press **MENU/OK** and select **PREMOTE** for MIC/REMOTE RELEASE.



Exposure Preview

To preview exposure in the LCD monitor, select PREVIEW EXP./WB for SCREEN SET-UP > PREVIEW EXP./WB IN MANUAL MODE.





Select an option other than **PREVIEW EXP./WB** when using the flash or on other occasions on which exposure may change when the picture is taken