Panoramas

Follow an on-screen guide to create a panorama.

1 Rotate the drive dial to □.



- 2 To select the size of the angle through which you will pan the camera while shooting, press the selector left. Highlight a size and press MENU/OK.
- **3** Press the selector right to view a choice of pan directions. Highlight a pan direction and press **MENU/OK**.
- 4 Press the shutter button all the way down to start recording. There is no need to keep the shutter button pressed during recording.
- 5 Pan the camera in the direction shown by the arrow. Shooting ends automatically when the camera is panned to the end of the guides and the panorama is complete.

