## 3 Close the battery-chamber cover. Close and latch the cover.




 If the cover does not close, check that the battery is in the correct orientation. Do not attempt to force the cover shut.



## Removing the Battery-

Before removing the battery, turn the camera off and open the battery-chamber cover.

To remove the battery, press the battery latch to the side, and slide the battery out of the camera as shown



The battery may become hot when used in high-temperature environments. Observe caution when removing the battery.