COOLING FAN SETTING

Adjust settings for optional cooling fans (\$\equiv 416\$).

Option	Description
AUTO1	The fan turns on automatically as required when camera
	temperature rises and runs at slow speed.
AUTO2	The fan turns on automatically as required when camera
	temperature rises and runs at high speed. The increased
	fan noise may be audible in movies.
LOW	Run the fan continuously at low speed.
HIGH	Run the fan continuously at high speed. The increased fan
	noise may be audible in movies.
OFF	Turn the fan off.

Connect to smartphones running the latest version of apps. The smartphone can then be used to:

- Control the camera and take pictures remotely
- Receive pictures uploaded from the camera
- Browse the pictures on the camera and download selected pictures
- Upload location data to the camera



For more information, visit: https://app.fujifilm-dsc.com/