
Using a Remote Release

A remote release can be used for long time-exposures. When using an optional RR-100 remote release or an electronic release from third-party suppliers, connect it to the camera's microphone/remote release connector via a third-party adapter that converts the female three-pin, ø2.5 mm connector to a male threepin, ø3.5 mm connector.



A confirmation dialog will be displayed when a remote release is connected; press MENU/OK and select ☐ REMOTE for MIC/ REMOTE RELEASE

