📥 📽 AF ILLUMINATOR

This item is also found in the photo menus (\blacksquare 152). Changes to one apply to the other.

FACE/EYE DETECTION SETTING

Enable or disable Intelligent Face Detection when recording movies.

Option	Description
FACE DETECTION ON	See "P FACE/EYE DETECTION SETTING" (19 153).
OFF	Intelligent Face Detection and eye priority off.



SUBJECT DETECTION SETTING

Options are the same as those for still photography, but settings must be adjusted separately (1911) 155).

① The camera automatically switches to continuous AF when SUBJECT DETECTION ON is selected for MAF/MF SETTING > MAFSUBJECT DETECTION SETTING, even if the focus mode selector is rotated to S. Subject detection is not available in manual focus mode.