HDMI OUTPUT INFO DISPLAY

If ON is selected. HDMI devices to which the camera is connected will mirror the information in the camera display.

Options	
ON	OFF

4K HDMI STANDBY QUALITY

Choose whether output to connected HDMI devices switches from 4K to Full HD during standby.

Option	Description
4K	Output to HDMI devices continues at 4K during standby.
	Output to HDMI devices switches to Full HD during standby, reducing the drain on the battery.

HDMI REC CONTROL

Choose whether the camera sends movie start and stop signals to the HDMI device when the shutter button is pressed to start and stop movie recording.

Options		
ON	OFF	

PHOTOMETRY

Options are the same as those for still photography, but settings must be adjusted separately (84).



The photometry option selected in the photo menus applies to movies recorded using function buttons that have been assigned MOVIE RECORDING RELEASE