## COMMAND DIAL SETTING

Choose whether to reverse the roles played by the front and rear command dials in each of the following modes.

Option	Description
P	Reverse the dials used for program shift and exposure compen-
	sation in mode <b>P</b> (program AE).
S	Reverse the dials used for shutter-speed selection and exposure
	compensation in mode <b>S</b> (shutter-priority AE).
A	Reverse the dials used for aperture selection and exposure
	compensation in mode <b>A</b> (aperture-priority AE).
М	Reverse the dials used for shutter-speed and aperture selection
	in mode <b>M</b> (manual).

## S.S OPERATION

Select **OFF** to disable shutter-speed fine-tuning using the command dials.

Options		
ON	OFF	

## **COMMAND DIAL DIRECTION**

Choose the direction in which the command dials are rotated to choose values. Settings for the front and rear command dials can be adjusted separately.

Option	Description
+	Rotate the dial right for higher values or to move to the next
	item.
+	Rotate the dial left for higher values or to move to the next item.