## **Recording Movies**

This section describes how to film movies in auto mode.

1 Slide the STILL/MOVIE mode switch to MOVIE.



2 Rotate the mode dial to P.



AUTO will appear in the display.



Rotate the mode dial only after pressing the dial lock release to release the dial.